

Supporting Information

Dual functional fluorescent sensor for selectively detecting acetone and Fe³⁺ based on {Cu₂N₄} substructure bridged Cu(I) coordination polymer

Yang Song^a, Ruiqing Fan*,^a, Xi Du^a, Kai Xing^a, Yuwei Dong^a, Ping Wang^a, and Yulin Yang*,^a

^a MIIT Key Laboratory of Critical Materials Technology for New Energy Conversion and Storage, School of Chemistry and Chemical Engineering, Harbin Institute of Technology, Harbin 150001, P. R. of China

Table S1 Selected luminescent compound materials for sensing acetone.

No.	luminescent materials	solution	detection limit	ref
1	{[Cd ₃ (L) ₂ (H ₂ O) ₆]·1.5DMF} (H ₆ L=4,4',4''-(methylsilanetriyl) tribenzoic acid)	aqueous solutions	3 vol% decreased by 83%	<i>Chin. Chem. Lett.</i> 2016, 27 , 497
2	[Cd(Tipb)(pta) _{0.5} (H ₂ O)-(NO ₃)] <cdot(dmf)<sub="">x(H₂O)_y (Tipb=2,4,6-tris[4-(1Himidazole-1-yl)]-benzene, pta = para-phthalate)</cdot(>	acetonitrile	0.084vol% decreased by 9469	<i>J. Mater. Chem. A</i> , 2014, 2 ,
3	[Cd(Tipb)(mta)] ·(DMF) _x (H ₂ O) _y (Tipb=2,4,6-tris[4-(1Himidazole-1-yl)]-benzene, mta= meta-phthalate)	acetonitrile	0.075vol% decreased by 9469	<i>J. Mater. Chem. A</i> , 2014, 2 ,
4	{[Tb ₄ (μ ₃ -OH) ₄ (BPDC) ₃ (BPDCA) _{0.5} (H ₂ O) ₆]ClO ₄ ·5H ₂ O (BPDC ²⁻ = 3,3'-dicarboxylate-2,2'-dipyridine anion and BPDCA ²⁻ = biphenyl-4,4'-dicarboxylate anion)}	EtOH	21vol%	<i>J. Phys. Chem. C</i> . 2014, 118 , 416
5	Ln(FBPT)(H ₂ O)(DMF) (Ln = Eu or Tb, FBPT = 2'-fluoro-biphenyl-3,4',5-tricarboxylate)	DMF	5%	<i>J. Mater. Chem. A</i> 2013, 1 , 11043
6	Tb(BTC)(H ₂ O) ₆ (BTC = benzenetricarboxylate)	aqueous suspension	0.3vol%	<i>J. Mater. Chem.</i> , 2012, 22 , 6819.
7	Cd ₃ (L)(H ₂ O) ₂ (DMF)2·5DMF (H ₆ L=hexa[4-(carboxyphenyl)oxamethyl]-3-oxapentane acid)	1-propanol	0.1vol%	<i>J. Mater. Chem.</i> , 2012, 22 , 23201.
8	Cd ₃ (L)(dib)·3H ₂ O·5DMA (H ₆ L=hexa[4-(carboxyphenyl)oxamethyl]-3-oxapentane acid, dib = 1,4-bis(1-imidazolyl)benzene)	1-propanol	0.1vol%	<i>J. Mater. Chem.</i> , 2012, 22 , 23201.
9	Yb(BPT)(H ₂ O)·(DMF) _{1.5} (H ₂ O) _{1.25} (BPT = biphenyl-3,4',5-tricarboxylate)	2-propanol	0.5vol%	<i>Chem. Commun.</i> 2011, 47 , 5551
10	Eu ₂ (pzdc)(pzdc)(ox)(H ₂ O) ₄ ·8H ₂ O	methanol	0.5vol%	<i>CrystEngComm</i> , 2010, 12 ,

	(pzdc = 2,5-pyrazinedicarboxylate, ox =oxalate)		4372.
11	Eu(BTC) (BTC = benzenetricarboxylate)	DMF 0.3 vol %	<i>Adv. Mater.</i> 2007, 19 , 1693
12	[Cu(tpp)•H ₂ O] _{2n} [H ₂ tpp = 1-(4-tetrazol-5"-yl)benzyl-3 - (pyrazinyl)pyrazole]	aqueous suspension 0.0842vol%	This work

Table S2 Selected luminescent compound materials for sensing Fe³⁺.

No.	luminescent materials	solution	K _{sv} / detection limit	ref
1	Ba ₅ (ADDA) ₅ (EtOH) ₂ (H ₂ O) ₃ ·5DMF H ₂ ADDA = 3,3'-(anthracene-9,10-diyl) diacrylic acid	methanol (turn-off) acetone (turn-off) THF (turn-on)	1.68×10 ⁴ / 10 ⁻⁶ M None/2.1×10 ⁻⁷ M -9.09×10 ³ / 10 ⁻⁶ M	<i>Inorg. Chem.</i> 2016, 55 , 1782
2	{[Eu(L)(H ₂ O) ₂] • NMP • H ₂ O} _n (NMP = Nmethyl-2-pyrrolidone)	DMF HEPES	3.83×10 ⁴ / none 2.55×10 ⁴ / none	<i>Inorg. Chem.</i> 2016, 55 , 10114
3	{[Cd ₃ (L) ₂ (H ₂ O) ₆] • 1.5DMF} (H ₃ L=4,4',4''-(methylsilanetriyl) tribenzoic acid)	aqueous solutions	None / 1×10 ⁻² M	<i>Chin. Chem. Lett.</i> 2016, 27 , 497
4	{[Tb ₄ (OH) ₄ (DSOA) ₂ (H ₂ O) ₈] _n ·(H ₂ O) ₈ }	aqueous solutions	3543 / none	<i>J. Mater. Chem. A.</i> 2015, 3 , 641
5	[Tb(BTB)(DMF)] · 1.5DMF · 2.5H ₂ O (H ₃ BTB = benzene-1,3,5-tribenzoate)	ethanol	None / 10 ⁻⁵ M	<i>Inorg. Chem.</i> 2015, 54 , 4585
6	EuL (L=2-aminoterephthalic acid)	DMF	2.88×10 ⁴ / none	<i>J. Mater. Chem. C,</i> 2014, 2 , 6758
7	[H ₂ N(CH ₃) ₂][Eu(H ₂ O) ₂ (BTMIPA)] · 2H ₂ O {H ₄ BTMIPA = 5,5'-methylenebis- (2,4,6-trimethylisophthalic acid)}	DMF	None / 10 ⁻³	<i>Chem. Commun.</i> 2013, 49 , 11557
8	EuL ₃ (L = 4'-(4-carboxyphenyl)-2,2': 6',2''- terpyridine)	aqueous solution	4.1 × 10 ³ /10 ⁻⁴ M	<i>ACS Appl. Mater. Interfaces</i> 2013, 5 , 1078
9	[Eu(BTPCA)(H ₂ O)] · 2DMF · 3H ₂ O (H ₃ BTPCA = 1,1',1''-(benzene-1,3,5-	DMF	None / 10 ⁻⁵ M	<i>Inorg. Chem.</i> 2013, 52 , 2799

triyl)tripiperidine-4-carboxylic acid

10	MIL-53(Al) (BDC = 1,4-benzenedicarboxylic acid)	aqueous solution	None / 0.9×10^{-6} M	<i>Anal. Chem.</i> 2013, 85 , 7441
11	Eu(C ₃₃ H ₂₄ O ₁₂)(H ₂ NMe)(H ₂ O)	HEPES aqueous	None / 10^{-4} M	<i>J. Mater. Chem.</i> 2012, 22 , 16920
12	Eu(acac) ₃ •Zn(C ₁₅ H ₁₂ NO ₂) ₂	CH ₂ Cl ₂ / MeOH	None / 5×10^{-3} M	<i>Chem. Commun.</i> 2011, 47 , 10731
13	[Cu(tpp)•H ₂ O] _{2n} [Htpp = 1-(4-tetrazol-5"-yl)benzyl-3 - (pyraziny-l)pyrazole]	aqueous suspension	$4.6 \times 10^4 / 10^{-5}$ M	This work

Table S3 Selected bond lengths [Å] and angles [°] for **1**.

Bond length	(Å)	Bond angle	(°)
Cu(1)-N(3)	1.976(4)	N(3)-Cu(1)-N(8)	111.62(14)
Cu(1)-N(8)	2.028(4)	N(3)-Cu(1)-N(6)	124.47(15)
Cu(1)-N(6)	2.076(4)	N(8)-Cu(1)-N(6)	107.32(15)
Cu(1)-N(4)	2.130(4)	N(3)-Cu(1)-N(4)	120.93(15)
Cu(2)-N(10)	2.005(4)	N(8)-Cu(1)-N(4)	109.28(14)
Cu(2)-N(16)	2.009(4)	N(6)-Cu(1)-N(4)	78.90(14)
Cu(2)-N(12)	2.088(4)	N(10)-Cu(2)-N(16)	110.79(15)
Cu(2)-N(14)	2.116(3)	N(10)-Cu(2)-N(12)	115.89(15)
		N(16)-Cu(2)-N(12)	113.66(16)
		N(10)-Cu(2)-N(14)	117.27(15)
		N(16)-Cu(2)-N(14)	117.16(15)
		N(12)-Cu(2)-N(14)	78.81(14)

Table S4 Standard deviation calculation and detection limit calculation.

Text 1 Fluorescence intensity	5842.45 a.u.
Text 2 Fluorescence intensity	5842.02 a.u.
Text 3 Fluorescence intensity	5841.25 a.u.
Text 4 Fluorescence intensity	5841.88 a.u.
Text 5 Fluorescence intensity	5842.11 a.u.
Standard Deviation (σ)	0.4402
Slope (m)	1568.14

Detection limit ($3\sigma/m$)	0.0842 vol%
---------------------------------	-------------




Fig. S1 The 1D chain structure of **1**.




Fig.S2 The IR spectra of **1**.




Fig.S3 The PXRD patterns of **1**.




Fig.S4 The TGA curves of compounds **1**.




Fig.S5 (a) Fluorescence intensity of compound 1 in different metal ion; (b) Results of the competition experiments between Fe³⁺ and selected other metal ions.




Fig.S6 Fluorescence intensity of compound 1 at 597 nm in different concentrations aqueous solutions of Fe³⁺ (in the range of approximately 10⁻⁶–10⁻² mol/L).