

Direct Cyanidation of Silver Sulfide by Heterolytic C-CN Bond Cleavage of Acetonitrile

Biraj Das,^{‡a} Pinku Saikia,^{‡a} Mukesh Sharma,^a Manash J. Baruah,^a Subhasish Roy,^b Kusum K. Bania^{a*}

^a*Department of Chemical Sciences, Tezpur University, Assam, India, 784028.*

^b*Department of Chemistry, School of Applied Sciences, University of Science and Technology, Meghalaya, Techno City, Kling Road, Baridua 9th Mile, Ri-Bhoi, Meghalaya, India 793101.*

[‡]Both the authors contributed equally

Corresponding Authors *E-mail: kusum@tezu.ernet.in.

ORCID: 0000-0001-6535-3913

1. Material and Physical Measurements

1.1 Material Used

Silver sulfide (Ag_2S) and vanadium pentoxide (V_2O_5) was procured from Sigma Aldrich and E-Merck, respectively. The solvents (Acetonitrile and Ethanol) employed during the synthesis procedure were purchased from E-Merck. HCl used during the UV analysis was procured from E-Merck.

1.2 Physical Measurement

XRD data's were recorded in a BRUKER AXS, D8 FOCUS instrument and low angle measurement from 10-80°.

Fourier-transform infrared spectra (FT-IR) of the materials were recorded on a Perkin-Elmer Spectrum 2000 FT-IR spectrometer in the range of 500-4000 cm^{-1} .

The SEM images and EDX analysis of Ag_2S and V_2O_5 were recorded in scanning electron microscopy of Model- Zeiss, Sigma and Make- Carl ZEISS Microscopy, Germany at an acceleration voltage of 5 kV.

The Raman analysis of the material was obtained in an EZRaman-N (Enwave Optronics) Raman Spectrophotometer, having laser light of 150 mW, 785 nm incident wavelength through 100x (0.3 N.A) objective lens.

The X-ray photoelectron spectroscopy (XPS) of the sample was measured using Mg $\text{K}\alpha$ (1253.6 eV) radiation as a source on a KRATOS (ESCA AXIS 165) spectrometer. The oven-dried samples (finely ground) were dusted on a graphite sheet (double stick) and mounted over the regular sample holder, before being transferred to an analysis chamber. Before recording the XPS, the material was outgassed overnight in a vacuum oven.

ESI-mass spectrums were recorded on ESI mass spectrometer from Agilent Technologies (1220 Infinity LC). High resolution mass spectrometry (HRMS) was recorded in a Q-Tof

ESI-MS instrument (model HAB 273) in acetonitrile (HPLC-grade). UV-vis absorption spectra for red solution were measured in Shimadzu, UV-2550 spectrophotometer.




Fig. S1 Raman spectra of XRD pattern of V₂O₅ (black), Ag₂S (red) and V₂O₅-Ag₂S (blue).




Fig. S2 SEM images (a-b) of V_2O_5 - Ag_2S (1:1 ratio) composite in different magnification.




Fig. S3 SEM images of Ag_2S .




Fig. S4 EDX analysis of the V_2O_5 - Ag_2S (1:1 ratio) composite.




Fig. S5 EDX analysis of the Ag_2S .




Fig. S6 XPS spectra for sulfur of the V₂O₅-Ag₂S composite on after solid state grinding.




Fig. S7 +ESI-MS of the reddish solution before AgCN extraction.




Fig. S8 HRMS of the reddish solution before AgCN extraction.




Fig. S9 HRMS of the aliquot after separation AgCN.