

Supporting Information

Rapid and Stable Hydrogen Detection Based on Pd-Modified WO₃ Nanosheets

Jianxin Lv,^a Linghui Zhang,^a Lianxi Si,^c Hui Li,^{ab} Wenbo Zhao,^a Fei An,^d Xia Feng^{a*} and Shi Hu^{ab*}

- a. Department of Chemistry, School of Science, Tianjin Key Laboratory of Molecular Optoelectronic Science, Tianjin University, Tianjin 300072, China.
- b. Institute of Energy, Hefei Comprehensive National Science Center Hefei, Anhui 230026, China.
- c. School of Chemical Engineering and Technology, Tianjin University, Tianjin 300072, China.
- d. State Key Laboratory of Safety and Control for Chemicals, SINOPEC Research Institute of Safety Engineering Co., Ltd, Songling Road No.339, Qingdao, 266000, China.

1. Measurement of hydrogen sensors

Fig.S1 shows the WS-30A gas-sensing system and the volume of test chamber is 18 L. Gas sensing performance can be tested by injecting a certain volume of gas from the gas injection hole. In this work, hydrogen was produced by a hydrogen generator (Success Hydrogen Energy Co., Ltd., Shandong, China). The detailed testing processes are as follows. Firstly, we tested the resistance of hydrogen sensor (R_a) in the test chamber filled with air. Then, we injected a certain volume of hydrogen, the hydrogen was mixed with air quickly. The changed resistance could be recorded by the test system. When the resistance value (R_g) was stable, we opened the test chamber and the sensor exposed to air again. The gas response was defined as $S=R_a/R_g$ (R_a represents initial resistance of the sensor in air and R_g represents its resistance in the target gas). The response and recovery time were defined as the time needed to reach 90% of the resistance change during gas adsorption and desorption.




Fig. S1 WS-30A gas-sensing system.




Fig. S2 (a) TEM and (b) HRTEM images of Pd/WO₃-1 sample.




Fig. S3 (a-c) TEM, HRTEM images and corresponding size histogram of Pd/WO₃-2 sample.




Fig. S4 (a-c) TEM, HRTEM images and corresponding size histogram of Pd/WO₃-3 sample.




Fig. S5 (a-c) TEM, HRTEM images and corresponding size histogram of Pd/WO₃-4 sample.




Fig. S6 XPS spectrum of full survey of Pd/WO₃-3 sample.




Fig. S7 (a) Gas response of WO_3 sample in the range of 20-2000 ppm of H_2 under 160 °C.




Fig. S8 (a) Gas response of Pd/WO_3 -1 sample in the range of 20-2000 ppm of H_2 under 160 °C.




Fig. S9 (a) Gas response of Pd/WO₃-2 sample in the range of 20-2000 ppm of H₂ under 160 °C.




Fig. S10 (a) Gas response of Pd/WO₃-3 sample in the range of 20-2000 ppm of H₂ under 160 °C.




Fig. S11 (a) Gas response of Pd/WO₃-4 sample in the range of 20-2000 ppm of H₂ under 160 °C.




Fig. S12 Resistance of the sensor based Pd/WO₃-3 to 200 ppm H₂ at 160°C during 50 cycles stability test.

Table S1. Pd content in the samples was measured by ICP.

Samples	Pd content
Pd/WO ₃ -1	0.19 %
Pd/WO ₃ -2	0.77 %
Pd/WO ₃ -3	3.51 %
Pd/WO ₃ -4	16.07 %




Fig. S13 (a) and (b) TEM images of Pd/WO₃-3 sample after all hydrogen sensing test.