

Electronic Supplementary Information

Surfactant-free co-solvent exfoliation strategy of semiconducting quasi-1D Nb₂Pd₃Se₈ nanowires

Kyung Hwan Choi,^{‡b} Yeongjin Kim,^{‡a} Jinsu Kang,^a Kyung In Kim,^a Jeong Su Park,^a Hyung-Suk Oh,^{a,d,e}
Hak Ki Yu^{*c} and Jae-Young Choi^{*a,b,e}

^aSchool of Advanced Materials Science and Engineering, Sungkyunkwan University, Suwon 16419, Korea

^bSKKU Advanced Institute of Nanotechnology (SAINT), Sungkyunkwan University, Suwon 16419, Korea

^cDepartment of Materials Science and Engineering & Department of Energy Systems Research, Ajou University, Suwon 16499, Republic of Korea.

^dClean Energy Research Center, Korea Institute of Science and Technology (KIST), Seoul 02792, Republic of Korea

^eKIST-SKKU Carbon-Neutral Research Center, Sungkyunkwan University, Suwon 16419, Republic of Korea

* Corresponding Authors: hakkiyu@ajou.ac.kr (H. K. Yu) and jy.choi@skku.edu (J. Y. Choi)




Fig. S1 Photographs of Nb₂Pd₃Se₈ dispersions in all cosolvent system after centrifugation at 6,000 rpm; IPA-water (top) and EtOH-water (bottom).




Fig. S2 UV-visible absorbance spectra of $\text{Nb}_2\text{Pd}_3\text{Se}_8$ dispersions processed in IPA-water co-solvent.




Fig. S3 UV-visible absorbance spectra of $\text{Nb}_2\text{Pd}_3\text{Se}_8$ dispersions processed in EtOH-water co-solvent.




Alcohol	Molecular structure	Molecular weight (g mol ⁻¹)	# of -CH ₃
Ethyl alcohol (EtOH)		46.068	1
Isopropyl alcohol (IPA)		60.1	2
Tert-butyl alcohol (TBA)		74.12	3

Fig. S4 Information of alcohols used as co-solvents in liquid exfoliation of Nb₂Pd₃Se₈




Fig. S5 Exfoliation results in TBA-water co-solvent. (a) Photographs of $\text{Nb}_2\text{Pd}_3\text{Se}_8$ dispersions in TBA 50% after centrifugation at 6,000 rpm. (b) UV-visible absorbance spectra of the $\text{Nb}_2\text{Pd}_3\text{Se}_8$ dispersions.

Solvents	Absorbance	Width (nm)
IPA 20%	0.514	31.3 ± 5.9
IPA 50%	0.684	21.0 ± 5.4
IPA 70%	0.585	29.7 ± 4.4
IPA 100%	0.371	35.8 ± 13.4
EtOH 30%	0.330	51.6 ± 16.5
EtOH 50%	0.575	30.4 ± 7.9
EtOH 80%	0.128	100.3 ± 37.9
NMP	0.633	23.4 ± 7.0

Fig. S6 Summary of the absorbance and average nanowire widths of different solvent compositions.




Fig. S7 Dispersion stability of $\text{Nb}_2\text{Pd}_3\text{Se}_8$ dispersions exfoliated in (a) IPA-water and (b) EtOH-water.




Fig. S8 (a) SEM images of $\text{Nb}_2\text{Pd}_3\text{Se}_8$ nanowires obtained from different co-solvent compositions. (b) Transfer curves of the devices. (c) Measured $I_{\text{on}}/I_{\text{off}}$ and mobility of the devices.