Supporting information

NIR-accelerated cascade reaction for degradation of organophosphorus compounds by Au/PTE/ZIF-8: Cooperative effect and mechanism

Fang Wang, ^{ab} Yi Ouyang,^b Pengfei Zhou,^{bc} Yan Zhang,^b Renjun Gao,^{*a} Bekir Engin Eser,^{*b} and Zheng Guo^{*b}

^a Key Laboratory for Molecular Enzymology and Engineering, The Ministry of Education, School of Life Science, Jilin University, Changchun 130021, China

^b Department of Biological and Chemical Engineering, Faculty of Technical Science,

Aarhus University, 8000 Aarhus, Denmark

^c Sericultural & Agri-Food Research Institute, Guangdong Academy of Agricultural Sciences, Key Laboratory of Functional Foods, Ministry of Agriculture and Rural Affairs, Guangdong Key Laboratory of Agricultural Product Processing, Guangzhou, 510610, China




Fig. S1 UV-VIS absorption spectra of Au and Au-PVP

Text S1 Calculation of photothermal conversion efficiency

The temperature change constant can be written as

$$\theta = \frac{T_t (T_t)}{T_{max} - T_0}$$

where T_t is the temperature at time t, T_0 is the initial solution temperature, and T_{max} is the maximum temperature that the solution can reach under NIR.

To evaluate the heat transfer time constant (τ_s),

$$\tau_s = -\frac{t}{ln\theta} \tag{2}$$

And the heat transfer coefficient is given as

$$h = \frac{\sum_{i} m_i C_{p,i}}{S\tau_s}$$
(3)

where m is the mass of the water, C_p is the heat capacity of the water, S is the surface area of the container, and m is the mass of the water.

The heat released from light absorbed by a container containing pure water (Q_0) can be determined by recording the temperature decay profile to the ambient temperature

$$Q_0 = \frac{cm\Delta T}{t} \tag{4}$$

where ΔT is defined as the temperature change of the solution after turning off the laser,

t is the heat

dissipation time of pure water.

Therefore, the photothermal conversion efficiency can be calculated by

$$\eta = \frac{hS(T_{max} - T_0) - Q_0}{P(1 - 10^{-A_{808}})}$$
(5)

where P is the laser power (2.5 W), A_{808} is the UV absorbance of the solution at 808nm




Fig. S2 The loaded enzymes SisLac and SanPox on different nanomaterials, AuNPs and Au/ZIF-8




Fig. S3 (a,b) The specific activity of Au/SisLac/ZIF-8 and Au/SacPox/ZIF-8 at different temperatures




Fig. S4 The calibration curves of (a) 4-AP, (b) 4-NP and (c) MP. The wavelengths for the spectrophotometry measurement of 4-NP and 4-AP were 410 and 630 nm, respectively. The wavelength for MP detection was 276 nm in the HPLC detection.